


# HW34-506

IP 65 Rated, NEMA 34 High Torque Step Motor

# **Recommended Drives**


- 1. STR8
- 2. ST Series: ST10 models

# Speed vs. Torque Curves





# **Duty Cycle Curves**



#### **Drive Configuration Details**

- 1. STR8
  - 1.1. Wire the motor to the drive using the parallel connection method.
  - 1.2. Select rotary switch position F for HT34-506.
  - 1.3. See the STR4/8 hardware manual for more setup details.
- 2. ST10 models
  - 2.1. Wire the motor to the drive using the parallel connection method.
  - 2.2. Use the ST Configurator<sup>™</sup> software to configure the drive and motor.
  - 2.3. Select HT34-478/506 from the "Standard motor" drop-down menu of the Motor dialog.
  - 2.4. See the relevant ST10 hardware manual for more setup details.

# **Additional Data**

Additional data for this motor, including a 2D drawing and a 3D model, are available for download from the Applied Motion website, <u>www.applied-motion.com</u>.